




Traka DockSafe Solutions

DockSafe Locker

Traka DockSafe Box

Traka DockSafe Box and Airline Lock

- 1 Driver arrives and is directed to a dock bay
- 2 Driver backs truck into bay
- 3 Driver goes to Drivers' Lounge
- 4 Key is deposited in locker and driver receives tally fob

- 1 Driver books in at Gatehouse
- 2 Gatehouse staff attach a temporary fob to drivers' keys
- 3 Driver backs truck into bay
- 4 Driver inserts temporary fob into external Traka DockSafe Box

- 1 Shunter Driver arrives for shift and retrieves shunter keys
- 2 Shunter Driver collects empty trailer and backs into bay
- 3 Shunter Driver retrieves airline lock from Traka DockSafe Box
- 4 Shunter Driver attaches airline lock to trailer and secures lock fob in Traka DockSafe Box

5 5 5 Securing vehicle keys and fobs in Traka Lockers or Traka DockSafe Boxes prevents vehicles or trailers from being moved. Once secured, warehouse operatives are notified the door is safe to open. Loading process begins and once loading is completed, loader closes door and keys or fobs are released.

- 6 Driver returns tally fob, retrieves keys and departs

- 6 Driver can now retrieve keys from Traka DockSafe Box
- 7 Driver drives off and iFob is removed from keys at gate

- 6 Shunter Driver can now retrieve airline lock fob from Traka DockSafe Box, remove airline lock and move trailer for collection and dispatch

Dock Door locked?



Key



Dock door is locked



Dock door is safe to open

ENTRY GATEHOUSE

DRIVERS' LOUNGE

EXIT GATEHOUSE